



HEATING ELEMENTS

- ☀️ **Basic heating** *Radiant:* Radiant front panel with integrated surface element. Manual reset overheat protection. (500 W)
- 🌀 **Quick heat** *Fan-forced heat:* Low-thermal-mass heating element combined with low-pressure centrifugal blower. Resettable overheat protection. (1000 W) Reset by turning heater off.

TEMPERATURE CONTROL

- 🌡️ **Electronic thermostat** Built-in electronic proportional-action thermostat ultrasensitive to 1/10°C (1/5°F) for radiant front panel.
- Timer** 0-120 minute resettable mechanical timer for quick heating.

CONTROL PANEL

- 📍 **Location** Located on the right hand side of the unit.
- 🕒 **Dial 1** Thermostat control with 3 mode-function selector (see below).
Dial 2 Timer dial.
- Mode-function selector** 3-mode-thermostat-function selector: Off; Radiant heat (500 W); Combined heat (1500 W).
- Indicator light** Heating indicator light.

CABINET

- 🏠 **Steel construction** with polyester/epoxy anti-rust powder coating.
- Cabinet** Splash-proof construction with rounded edges and built-in side wire covers.
- Louvres** Bottom grille directs the hot air downwards, towards the centre of the room to ensure even temperature.
- Filter** Easy-to-clean, removable rear-mounted dust filter for easier maintenance.
- Accessories** Two (2) bars and two (2) pegs included.
- Color BB** = White

INSTALLATION

- 🔧 **Installation** Quick-mounted surface installation with screw-in bracket.
- Connection** Flexible armoured power cord supplied with heater. Installation requires wall box (not included).
- Installation height** 10 in (25 cm).
- Clearances** ■ **Front:** 20 in (50 cm) ◀️ **Sides:** 4 in (10 cm) ▲ **Above:** Above: 12 in (30.5 cm).

MODEL	Catalog No.	Color	Power 240-V	Height		Width		Thickness		Weight	
				cm	in	cm	in	cm	in	kg	p
DIVA ②	7646-C15	BB	* 500 - 1500 W	107	42	47	18 1/2	15	5 3/4	17,0	37,4
* Radiant (500 W); Radiant and fan-forced heat (1500 W).				WITH BARS		51	20	22,5	9	--	--

② Compatible with the Convectair Programmer system (see technical specifications for catalogue number 7392).

For guaranteed, dependable operation, we recommend that all units be installed by a licensed electrical contractor.

